



HIGH PERFORMANCE HYPERSPECTRAL SYSTEMS

# RobotEye REHS25 Hyperspectral Ultrafast Broadband Spectral Scanner

# Product Datasheet





### RobotEye REHS25 Hyperspectral— An Ultrafast Broadband Spectral Scanner

The RobotEye REHS25 Hyperspectral is a high performance broadband spectral scanner with unprecedented speed and flexibility in the acquisition and mapping of spectral data. RobotEye hyperspectral scanners transform any single point spectrometer into a mapping hyperspectrometer. These hyperspectral imaging systems couple the unmatched range of motion and pointing precision of the RobotEye with any commercial off-the-shelf single point spectrometer to achieve rapid imaging with both high spatial and spectral resolution.

The RobotEye core technology on which the REHS25 is based enables the view of the spectrometer to be steered with simultaneous speed and precision while the spectrometer itself remains completely stationary. Ultrafast RobotEye hyperspectral scanners are the only spectral acquisition systems which isolate the spectrometer from its field of view, and in doing so enable applications which were previously not possible. The unique characteristics of the REHS25 include:

Your Choice of Spectrometer: The RobotEye ultrafast and precise pointing capability can be used to transform any single point spectrometer into an imaging hyperspectrometer. The spectrometer in a RobotEye hyperspectral system is attached via a fiber optic SMA connector and remains stationary at all times, giving the user complete freedom to attach a spectrometer perfectly matched to the application. Whether your spectrometer is the size of a shipping box or a matchbox, 50 grams or 50 kilograms there is no difference in the pointing dynamics attainable with RobotEye spectral scanners.

Wide Spectral Range: The RobotEye REHS25 has been designed for a wide range of applications having a spectrally >90% flat transmission across its 400 nm to 2500 nm wavelength range. The RobotEye optical path may also be optimised for a narrower band-pass within its 400 nm to 2500 nm wavelength range.

High Acquisition Speed: The RobotEye Hyperspectral REHS25 is an ultrafast hyperspectral imaging system, enabling large scenes to be imaged in short time periods. This has been achieved as a result of the unmatched pointing dynamics of the RobotEye across 360° in azimuth and 70° in elevation.

High Pointing Precision: The RobotEye core technology on which the REHS25 is based, is the only technology on the market which enables the view of the spectrometer to be steered with simultaneous speed and precision. The pointing precision of the RobotEye gives the users the ability to pin-point the scanning, and to image down to a very fine spatial resolution without compromising on scan time.

Ease of Integration: The RobotEye Hyperspectral REHS25 connects to your spectrometer simply via a fiber optic SMA connector, all without the need for time consuming and costly modifications. Further, the RobotEye C++ Development Library enables straightforward integration with your application. Automation of the spectral mapping for any region of interest, at any desired spatial resolution, or even just the measurement of discrete points is easily achieved.



Robustness: RobotEye REHS25 Hyperspectral has been built for all environments. The RobotEye core technology has a natural immunity to shock and vibration. Further, physical separation of the robust RobotEye scanning head from the stationary spectrometer allows for installation in even the most extreme environments.



## RobotEye REHS25 Hyperspectral Specifications

Mechanical		Spectral	
Maximum Scan Rate	25 measurements/s	Spectral Range	400—2500 nm
Azimuth Axis Resolution	0.010°	Spectrometer Connector Type	SMA Fiber Optic Adaptor
Elevation Axis Resolution	0.010°	Software	
Azimuth Range	360° Continuous	RobotEye C++ Development Library	Windows/Linux
Elevation Range	70° (±35°)	Environmental	
Accuracy	0.05°	Operating Temperature Range*	-20°C - +70°C
Weight	2.5 kg	IP Class Rating **	65
Electrical		<ul> <li>Does not include temperature rating of the spectrometer used with the system</li> <li>IP Rating valid only when both supplied power &amp; optionally supplied weatherproof</li> </ul>	
Communication	Ethernet	<ul> <li>** IP Rating valid only when both supplied power &amp; optionally supplied weatherproo Ethernet cable connectors are fitted.</li> </ul>	
Supply Voltage	24 VDC		
Power Consumption — Typical (average)	< 40 W		
— Transient	200 W	-	



Specifications are subject to change without notice



### RobotEye C++ Development Library

The REHS25 ships with a fully documented C++ class library for both Windows and Linux. This library can be used to simply and quickly interface to the REHS25 enabling rapid application development for REHS25 owners. The library provides access to the entire range of functions available to the REHS25 and its reference manual is available to download from our website.

The RobotEye C++ Development Library includes a range of motion commands to support all user scan behaviours, the most relevant of which is SetApertureAngles. The SetApertureAngles command enables rapid and precise positioning of the system aperture at up to 25 distinct locations per second within the 360° by 70° range of motion. SetApertureAngles function allows the REHS25 to point with a spatial resolution of up to 0.01° in both azimuth and elevation. This function enables the rapid imaging of any region at any desired resolution.

The RobotEye C++ Development Library also provides a low latency method for accessing the current system aperture direction. GetApertureAngles function provides low latency access to the current system aperture position on request, and may be used in conjunction with SetApertureAngles.

#### **Control & Communication**

REHS25 requires a 24 VDC power connection and a 100 Megabit Ethernet connection for control of the REHS25 scanning behaviour. Communication with and control of the REHS25 is achieved via the system's Ethernet port. Full control over the motion of the system aperture and system feedback including current aperture orientation is enabled through the RobotEye C++ Development Library.

#### Standard System Components

- RobotEye REHS25 HYPERSPECTRAL
- 5 metre power cable
- RobotEye C++ Development Library

#### **Optional System Components**

- 10 metre weatherproof Ethernet cable
- A range of VIS, NIR and SWIR bandpass filters



Ocular Robotics Ltd Unit F1 13-15 Forrester Street Kingsgrove NSW 2208 Australia

phone:+ 61 2 9090 2630fax:+ 61 2 8094 9135email:sales@ocularrobotics.comweb:www.ocularrobotics.comtwitter:@OcularRobotics

